

Click to prove  
you're human































Welcome back to another article on military time. If you have learned how to read and pronounce military time with us in another article, it is good to go ahead and learn how to change a watch from military time to standard time and vice versa. Whatever reason you have to use a particular time system, it is handy to have the steps in mind since you do not have to go searching on the Internet every time you need to make the switch. Understanding this, here we have an article that will take you through all the necessary steps, which are briefly summarized as follows: For a standard digital watch: Hit MODE three times Hit RESET twice Hit START until the time passes 24 hours Hit START until you get the time you want For an Apple Watch: Turn your Apple Watch and iPhone on Open the Watch app and select CLOCK Turn the 12-HOUR TIME on with swiping motions For a Marathon WR50M watch: For a complete set of instructions, continue to read! Step-by-step Guide: Change Watch to Military Time1. Standard Digital WatchThis is the type of watch found in local stores like Walmart, Walgreens, Target, Best Buy, etc. It should have four buttons, which are the start, reset, light, and mode functions. Hit the MODE function once, which will take you to the stopwatch. Hit the MODE one more time to get the RLE. This shows you the alarm clock. But, since this is not what we want, so hit MODE again. When you see that the display is blinking, hit the RESET twice. At this point, you should see that the cursor is at the hours digits. Click START to change the hours. Do this until you pass 24 hours. It will automatically revert to 12. The H letter at the bottom of the display will also change from H to A. Completely by setting the hour to the time you want in a 12-hour format. 2. Apple WatchIf you are an Apple user, you may wonder how to change my apple watch from military time? Lucky for you, this section is dedicated to answering that! The Apple Watch has a default 12-hour time format. So, it runs from 1 AM to 12 PM and then from 1 PM to 12 am. Sometimes, for some reason, your phone may be switched to military time. You can return to the standard time with four simple steps. First, turn on your Apple Watch and iPhone. Make sure that the phone is paired with your watch through iOS. Open the Watch app on the phone and select CLOCK in the top right corner. Then, turn off the 24-HOUR TIME format by sliding or swiping it until you can select the 12-HOUR TIME format. When you want to return to military time, carry out the same steps. However, note that you will see military time on the display if you set the watch face to DIGITAL style. In case your watch does not have a DIGITAL watch face, install it in the Watch app. You can check this in the Watch apps WATCH FACE GALLERY. Note: You need to make sure that the time mode change syncs and is apparent on both your iPhone and Apple Watch. Otherwise, you will have to redo it over and over because the sync will not be permanent. If it does not sync, follow these steps to change your iPhones time to the 12-hour time format: First, turn your phone on and open the SETTINGS app. Go to GENERAL and click on the DATE & TIME option. Finally, switch on the 12-HOUR TIME. Furthermore, here is a detailed guide to changing the time on the Apple watch for Ifan. 3. Timex Marathon WR50M WatchThere is only one step that you need to take to change Marathon WR50M watch from military time to standard time and vice versa. Yes, you read that right! Only one step! So, what's the step? It's: press the SET button on the left of the watch once. You should see the time change from a military format to a standard format. Click it again to change back to military time. Voila! Top Tip: Its easier to press the SET button if you take the watch off your wrist. If you want a visual guide, watch this YouTube video. ConclusionCongrats, you have seen the instructions on how to change a watch from military time to standard time for three types of watches: the standard digital watch, Apple Watch, and Timex Marathon WR50M watch. And if you are wondering why the military use 24-hour instead of 12-hour, this post will help you find the answer! Hopefully, you were able to follow along and change the time formats on your own watch. If you have any additional queries or thoughts, feel free to reach out to us in the comments below! Also, please do not hesitate about sharing this articles content with others, especially those you know are struggling with changing the time mode on their watch! Read more: Detail steps to change a G-Shock to military time am Everett Bledsoe, taking on the responsibility of content producer for The Soldiers Project. My purpose in this project is to give honest reviews on the gear utilized and tested over time. Of course, you cannot go wrong when checking out our package of information and guide, too, as they come from reliable sources and years of experience. About Adjustable Black 15mm Resin Strap, Fits Around Wrist 24-Hour Stopwatch, Customizable Daily Alarm, 2 Time Zones 24-Hour Military Watch, Selectable Time Chime: Date Black acrylic lens, gray case 43mm; Indiglo Luminous Watch Dial Water Resistant to 50 meters (165 feet); Generally suitable for short swims, but not for diving or snorkeling EXTENDED WARRANTY Available in the U.S. only. Extend your warranty for an additional 4 years from the date of purchase for \$5. You can pay with AMEX, Discover, Visa, or MasterCard by calling 1 800-448-4639 during normal business hours. Payment must be made within 30 days of purchase. Name, address, telephone number, purchase date, and 5-digit model number required. You can also mail a check for \$5 to Timex Extended Warranty, P.O. Box 1676, Dept. EF, Little Rock, AR 72203. Please read the instructions carefully to understand how to operate your Timex watch. Your model may not have all of the features described in this booklet. FEATURES AND BASIC OPERATION Date with MM-DD (month/day) format Daily Alarm with Snooze feature Hourly Chime 24-Hour Stopwatch with Split time INDIGLO night-light Button functions are shown with setting functions in parentheses TIME To set a time and date Press MODE until you get to the screen where the seconds can be seen flashing. Press ST/STP/ALM to set Seconds to zero adding one minute if seconds are 30 or greater. Press RESET/NEXT to set Hours, as indicated by its flashing. Press ST/STP/ALM to advance the Hours setting. Press and hold to increment quickly. Note: As the Hours are incremented, the time indicator changes from A (AM) to P (PM) to H (24-hour time) Press RESET/NEXT to set Minutes, as indicated by its flashing. Press ST/STP/ALM to advance the Minutes setting. Press and hold to increment quickly. Press RESET/NEXT to set the Day, as indicated by its flashing. Press ST/STP/ALM to advance the Day setting. Press and hold to increment quickly. Press RESET/NEXT to set the Day of the Week, as indicated by its flashing. Press ST/STP/ALM to advance the Day of the Week set. Press and hold to increment quickly. Press MODE to exit Time Set. STOPWATCH Use this function for timing events. Press MODE until ST appears. Press ST/STP/ALM to start timing. With the stopwatch running, press RESET/NEXT to record a Split time. The stopwatch will continue timing in the background. Press RESET/NEXT to release the display and show the current running stopwatch time. 5. Press RESET/NEXT to record another Split time. Press ST/STP/ALM to pause the timing. Either press ST/STP/ALM to resume timing, or press RESET/NEXT to reset the Stopwatch to zero. ALARM To turn on/off or to set a Daily alarm with a one-time snooze feature. To turn on/off an hourly chime. 1. Press MODE until AL appears. Press ST/STP/ALM repeatedly to turn on/off the Alarm (ALM ) or the Hourly Chime (CHI, SIG or ) or both. To Set the Alarm, press RESET/NEXT. The Hour digit flashes and the Alarm ON (ALM or ) lights. Press ST/STP/ALM to advance the Hours setting. Press and hold to increment quickly. Note: The Hours will be presented in the same format (12- or 24-hour time) as the time setting. Press RESET/NEXT to set the Minutes as indicated by its flashing. Press ST/STP/ALM to advance the Minutes setting. Press and hold to increment quickly. 6. Press RESET/NEXT to exit the Alarm Setting mode. 7. When the alarm sounds: Press ST/STP/ALM or RESET/NEXT to stop the alert, and the alarm will sound at the same time on the next day. OR Press MODE while the alarm is sounding. This will stop the alarm and postpone it 5 minutes. WATER RESISTANT Your watch is water-resistant and should be used for diving, too. 2. Watch not a diver watch and should not be used for diving. 3. Rinse the watch with fresh water after exposure to salt water. 4. Shock resistance will be indicated on the watch face or case back. Watches are designed to pass the ISO test for shock resistance. However, care should be taken to avoid damaging the crystal/lens. REFERENCE LINK PDF Timex Marathon Digital Watch Buy on Amazon The Timex Marathon watch is a popular choice for athletes, runners, and anyone needing a durable and reliable timepiece. If applicable, push the reset button when replacing the battery. Battery type is indicated on the case back. Battery life estimates are based on certain assumptions regarding usage; battery life may vary depending on actual usage. DO NOT Note: The Alarm ON (ALM or ) will flash to confirm Snooze mode. INDIGLO NIGHT-LIGHT Press the INDIGLO button to illuminate the watch display for 2-3 seconds. Electroluminescent technology used in the INDIGLO night-light illuminates the watch face at night and in low light conditions. How do I set up my Timex Marathon digital watch? Please carefully read the instructions on how to operate your Timex watch. Press MODE again to switch between modes: Alarm, Stopwatch, and Second Timer. Press the MODE button to exit the current mode and return to the clock mode. To set the time and date: 1) When the time and date are displayed, press and hold the SET button for 2 seconds. Is marathon a good name? When you think of Marathon watch brands, you probably think of military watches. In fact, the brand is an excellent example of combining functionality and functionality to meet the needs of military watches. That said, Marathon makes some of the best military watchmakers on the market. Product specifications Brand, Seller, or Collection Name Marathon by Timex Model number TW5K94800 Part Number TW5K94800 M6Item Shape Round Dial window material type Acrylic Display Type Digital Clasp Buckle Case material Resin Case diameter 43 millimeters Case Thickness 15 millimeters Band Material Resin Band size Mens Standard Band width 15 millimeters Band Color Black Dial color Gray Bezel material Resin Bezel function Stationary Calendar Day-Date Special features Chronograph Weight 1.76 Ounces Movement Quartz Water resistant depth 50 Meters WARNING: TO MAINTAIN WATER RESISTANCE, DO NOT PRESS ANY BUTTONS UNDER WATER. The watch is water-resistant only as long as the seconds can be seen flashing. Press ST/STP/ALM to set Seconds to zero adding one minute if seconds are 30 or greater. Press RESET/NEXT to set Hours, as indicated by its flashing. Press ST/STP/ALM to advance the Hours setting. Press and hold to increment quickly. Note: As the Hours are incremented, the time indicator changes from A (AM) to P (PM) to H (24-hour time) Press RESET/NEXT to set Minutes, as indicated by its flashing. Press ST/STP/ALM to advance the Minutes setting. Press and hold to increment quickly. Press RESET/NEXT to set the Day, as indicated by its flashing. Press ST/STP/ALM to advance the Day setting. Press and hold to increment quickly. Press MODE to exit Time Set. STOPWATCH Use this function for timing events. Press MODE until ST appears. Press ST/STP/ALM to start timing. With the stopwatch running, press RESET/NEXT to record a Split time. The stopwatch will continue timing in the background. Press RESET/NEXT to release the display and show the current running stopwatch time. 5. Press RESET/NEXT to record another Split time. Press ST/STP/ALM to pause the timing. Either press ST/STP/ALM to resume timing, or press RESET/NEXT to reset the Stopwatch to zero. ALARM To turn on/off or to set a Daily alarm with a one-time snooze feature. To turn on/off an hourly chime. 1. Press MODE until AL appears. Press ST/STP/ALM repeatedly to turn on/off the Alarm (ALM ) or the Hourly Chime (CHI, SIG or ) or both. To Set the Alarm, press RESET/NEXT. The Hour digit flashes and the Alarm ON (ALM or ) lights. Press ST/STP/ALM to advance the Hours setting. Press and hold to increment quickly. Note: The Hours will be presented in the same format (12- or 24-hour time) as the time setting. Press RESET/NEXT to set the Minutes as indicated by its flashing. Press ST/STP/ALM to advance the Minutes setting. Press and hold to increment quickly. 6. Press RESET/NEXT to exit the Alarm Setting mode. 7. When the alarm sounds: Press ST/STP/ALM or RESET/NEXT to stop the alert, and the alarm will sound at the same time on the next day. OR Press MODE while the alarm is sounding. This will stop the alarm and postpone it 5 minutes. WATER RESISTANT Your watch is water-resistant and should be used for diving, too. 2. Watch not a diver watch and should not be used for diving. 3. Rinse the watch with fresh water after exposure to salt water. 4. Shock resistance will be indicated on the watch face or case back. Watches are designed to pass the ISO test for shock resistance. However, care should be taken to avoid damaging the crystal/lens. REFERENCE LINK PDF Timex Marathon Digital Watch Buy on Amazon The Timex Marathon watch is a popular choice for athletes, runners, and anyone needing a durable and reliable timepiece. One of its features is the ability to display time in either 12-hour (AM/PM) or 24-hour (military) format. Switching between these formats is straightforward, but can be confusing if you're not familiar with the process. Here's how to do it: On most Timex Marathon models, to change from military time (24-hour format) to standard time (12-hour format), you'll typically need to press and hold the Mode button (or a similarly labelled button) until the display blinks or changes. You may need to consult your specific watch models manual, as button configurations can vary. Is this article helpful to you? Understanding Time Formats on Your Timex Marathon Many users appreciate the military time feature for its clarity, especially in situations where avoiding ambiguity is crucial. However, most people are more accustomed to the 12-hour clock, which separates the day into two 12-hour periods designated as AM (ante meridiem, before noon) and PM (post meridiem, after noon). Knowing how to switch between these formats ensures you can use your Timex Marathon in the way that best suits your needs. Step-by-Step Guide to Changing Time FormatsHere's a more detailed guide on how to typically change the time format. Keep in mind that specific button names and sequences might vary slightly depending on your exact Timex Marathon model. Identify the Mode button: Locate the button on your watch that allows you to navigate through different settings and modes. This is often labelled Mode, but it could also be Set or a similar term. Refer to your watches manual if you're unsure. Enter Setting Mode: Press and hold the Mode button for a few seconds. You should see the display start to blink, indicating that you've entered setting mode. Navigate to the Time Format Option: Once in setting mode, press the Mode button repeatedly to cycle through the available settings. Look for an option that relates to time format, which may be displayed as 12/24, HR Format, or something similar. Change the Time Format: Once you've located the time format option, use the anser button (often the Start/Stop or Reset button) to toggle between the 12-hour and 24-hour formats. Exit setting mode: After pressing of this button should press the format back and forth. Confirm Your Selection: After selecting your desired time format (12-hour or 24-hour), press the Mode button again to confirm your choice and move to the next setting. Exit Setting Mode: Continue pressing the Mode button to cycle through any remaining settings until you return to the normal time display. The watch should now be displaying the time in your chosen format. Tips for SuccessConsult Your Manual: The best resource for accurate instructions is always your watches manual. If you don't have a physical copy, you can often find it online on the Timex website. Battery Life: A low battery can sometimes cause issues with settings. If you're having trouble changing the time format, try replacing the battery. Button Functionality: Ensure that all the buttons on your watch are functioning correctly. If a button is stuck or unresponsive, it might be preventing you from accessing the settings. Resetting: If you're still having trouble, you can try resetting your watch to its factory settings. However, be aware that this will erase all of your stored data, such as split times and alarms. See 3,000+ New Gun Deals HERE Troubleshooting Common IssuesIf you're encountering difficulties while attempting to change the time format on your Timex Marathon watch, here are some common issues and their possible solutions: Watch Not Entering Setting Mode: Make sure you're pressing and holding the correct button (usually the Mode button) for the required duration. Also, ensure that the battery is not too low. Unable to Locate Time Format Option: Check your watches manual for the exact name of the time format setting. It might be labelled differently depending on the model. Button Not Working: Try cleaning the button with a soft, dry cloth. If the button is still unresponsive, it might need to be repaired or replaced. Display Freezing or Glitching: A low battery or a software glitch can sometimes cause display issues. Try replacing the battery or resetting the watch. FAQs About Timex Marathon Watch Time Format1. How do I know if my Timex Marathon is in military time? If your watch displays the hours from 00 to 23, it is set to military time (24-hour format). The 12-hour format will show hours from 1 to 12, along with an AM or PM indicator. 2. What does Mode mean on my Timex watch? The Mode button is typically used to cycle through different functions and settings on your watch, such as time, date, alarm, stopwatch, and setting options. 3. Can I accidentally change the time format on my watch? Its possible, especially if you accidentally press and hold the Mode button. Being aware of the button functions and familiarizing yourself with the setting process can minimize this risk. 4. What if I don't have the manual for my Timex Marathon? You can usually find a PDF version of the manual on the Timex website or by searching online for your specific watch model. 5. Does the Timex Marathon always show the seconds? Whether the seconds are always displayed depends on your watch model and settings. Some models allow you to choose whether to display seconds in the main time display. See 3,000+ New Gun Deals HERE 6. How often should I change the battery in my Timex Marathon? Battery life varies depending on usage, but typically you'll need to replace the battery every 1-3 years. 7. Will changing the time format affect my alarm settings? No, changing the time format should not affect your alarm settings. Your alarms will still be set to the same times, regardless of whether the watch is in 12-hour or 24-hour format. 8. What other functions does the Timex Marathon watch have? The Timex Marathon typically includes features such as a stopwatch, alarm, date display, and Indiglo night-light. Some models may also have interval timers or other specialized functions. 9. Is the Timex Marathon waterproof? The Timex Marathon is typically water-resistant to a certain depth, usually 50 or 100 meters. Refer to your watches manual for the specific water-resistance rating. 10. Can I change the band on my Timex Marathon watch? Yes, most Timex Marathon watches have interchangeable bands. You can typically find replacement bands online or at watch stores. 11. Why is my watch showing the wrong time after changing the battery? After changing the battery, you may need to reset the time and date. Follow the instructions in your watches manual to set the time correctly. 12. What does the Indiglo feature do on the Timex Marathon? The Indiglo feature provides a uniform backlight for the watch face, making it easier to read the time in low-light conditions. 13. How do I reset my Timex Marathon to factory settings? The reset procedure varies depending on the model. Typically, it involves pressing and holding a combination of buttons. Consult your manual for specific instructions. Be aware that resetting will erase all of your stored data. See 3,000+ New Gun Deals HERE 14. Is the Timex Marathon a good watch for running? Yes, the Timex Marathon is a popular choice for runners due to its lightweight design, durability, water resistance, and essential features like a stopwatch and timer. 15. Where can I get my Timex Marathon repaired? You can typically get your Timex Marathon repaired at a local watch repair shop or by contacting Timex customer service directly. Check the Timex website for authorized repair centers. By following these instructions and FAQs, you should be able to easily change the time format on your Timex Marathon watch and troubleshoot any common issues you may encounter. Remember to always consult your watches manual for the most accurate and specific information. Product Manual: Ironman Mid-Size 10-Lap Type: Digital Specs: CR2025 battery and model 010 Product Manual: Mid-Size Digital Sports Watch Type: Digital Specs: CR2025 battery and model 05B, 06J, 09N Product Manual: Timex Digital 33mm Type: Digital Specs: CR2032 battery and model 02M Product Manual: Quartz Analog with Tide Tracker at 3 and Date at 6 Type: Analog Specs: SR927SW battery and model 06S Product Manual: Men's Ironman Transi+ Type: Digital Specs: CR2032 battery and model 08V Product Manual: Kids Digital Sport Type: Digital Specs: CR2016 battery and model 11W Product Manual: Quartz Analog Moonphase Multifunction Type: Analog Specs: SR621SW battery and model 247 Product Manual: Expedition Trail Series Digital-Analog Combo Type: Digital / Analog Combo Type: Digital Specs: CR2016 battery and model 930, 931 Product Manual: 2-Hand Quartz Analog Type: Analog Specs: SR626SW battery and model 060, 253 Product Manual: GMT Quartz Analog with Date Type: Analog Specs: SR920SW battery and model 06S Product Manual: Redemption and Rush Digital Type: Digital Specs: CR2025 battery and model 09M Product Manual: SSQ Digital Reissue Type: Digital Specs: CR2016 battery and model 12A Product Manual: Chronograph with Sub-dials at 3 9 Type: Analog Specs: SR616SW battery and model 261 Product Manual: Women's Ironman 30-Lap Type: Digital Specs: CR2016 battery and model 95S Product Manual: UFC 30 Anniversary and Timex x Seconde Seconde Quartz Analog Type: Analog Specs: CR2016 battery and model 131 Product Manual: Classic Digital Type: Digital Specs: CR2025 battery and model 11C Product Manual: Connect Active+ Type: Digital Specs: Rechargeable battery and model 08Y Product Manual: Women's 3-Hand Full-Size Analog Date Type: Analog Specs: SR626SW battery and model 00V, 02C, 09J, 203, 230, 265, 279, 684 Product Manual: Full-Size Sport Digital Type: Digital Specs: CR2025 battery and model 042, 083 Product Manual: Timex Q LCA Quartz Digital Type: Digital Specs: CR2025 battery and model 04K Product Manual: Chronograph with Sub-dials at 6 9 12 and Date at 3 Type: Analog Specs: SR936SW battery and model 08X Product Manual: Full-Size 3-Hand Quartz Analog with Date Type: Analog Specs: SR920SW battery and model 207 Product Manual: Ironman Adrenaline Digital Type: Digital Specs: CR2016 battery and model 09Z Product Manual: Small 2-Hand Quartz Analog Type: Analog Specs: SR516SW battery and model 259 Product Manual: Men's Multi-Function Quartz Analog Type: Analog Specs: SR927SW battery and model 00R Product Manual: Metropolitan R Type: Digital Specs: Rechargeable battery and model 06A Product Manual: Chronograph with Sub-dials at 3 6 9 and Date at 5 Type: Analog Specs: SR927SW battery and model 08W Product Manual: Q Timex 3-Hand Quartz Analog Reissue Type: Analog Specs: SR626SW battery and model 732 Product Manual: Digital Pedometer Step + Distance + Calorie Type: Accessory Specs: SR1130W battery and model 621 Product Manual: Intelligent Quartz World Time Type: Analog Specs: CR2016 battery and model 304 Product Manual: Ironman 100-Lap Fix Type: Digital Specs: CR2025 battery and model 814 Product Manual: Quartz Analog Multi-Function Day/Date Type: Analog Specs: SR920SW battery and model 095 Type: Digital Specs: CR2016 battery and model 363 Type: Analog Specs: CR2016 battery and model 190 Type: Analog Specs: SR626SW battery and model 00G Type: Digital Specs: SR626SW battery and model 08X Type: Digital Specs: CR2032 battery and model 10G, 10L, 10N Type: Digital Specs: CR2016 battery and model 029, 030, 11G Type: Analog Specs: SR936SW battery and model 01L Type: Analog Specs: SR936SW battery and model 01N Type: Digital Specs: CR2016 battery and model 334, 866, 867 Type: Digital Specs: CR2016 battery and model 098 Type: Automatic Specs: Automatic self-winding movement and model 02N, 05D, 05G, 09F, 10S, 10V, 11E Type: Digital Specs: CR2032 battery and model 032 Type: Analog Specs: CR2016 battery and model 957 Type: Analog Specs: Solar powered and model 01K, 06R, 10T Type: Analog Specs: CR2016 battery and model 902, 905, 91B Type: Analog Specs: CR2016 battery and model 903, 916 Type: Analog Specs: SR626SW battery and model 035 Type: Digital Specs: CR2016 battery and model 854 Type: Digital Specs: SR521SW battery and model 11B Type: Analog Specs: SR920SW battery and model 01C Type: Analog Specs: SR920SW battery and model 03B Type: Digital Specs: CR2025 battery and model 075 Type: Digital Specs: CR2025 battery and model 09G Type: Digital Specs: CR2032 battery and model 076 Type: Digital Specs: CR2032 battery and model 09X Type: Digital Specs: CR2016 battery and model 745 Type: Analog Specs: SR621SW battery and model 04P Type: Analog Specs: SR521SW battery and model 288 Type: Digital Specs: CR2025 battery and model 036 Type: Analog Specs: SR920SW battery and model 209 Type: Analog Specs: CR2032 battery and model 10D Type: Digital / Analog Combo Specs: CR2025 battery and model 08T Reddit and its partners use cookies and similar technologies to provide you with a better experience. By accepting all cookies, you agree to our use of cookies to deliver and maintain our services and site, improve the quality of Reddit, personalize Reddit content and advertising, and measure the effectiveness of advertising. By rejecting non-essential cookies, Reddit may still use certain cookies to ensure the proper functionality of our platform. For more information, please see our Cookie Notice and our Privacy Policy. Jupiter Images/Goodshoot/Getty Images Timex analog 24-hour watches feature a special miniature clock face or "dial" that shows the time in the 24-hour format, also referred to as military or astronomical time in the United States and Canada. This feature is useful since conventional analog watches do not differentiate between AM and PM, which can be a problem if you ever need to determine the time in 24-hour format from your watch. The 24-hour dial automatically moves when the time is set meaning that the time on your watch is incorrect if the 24-hour dial is showing the wrong time. Setting the 24-hour time on your Timex analog or digital watch takes only a few seconds. Locate the "Crown" dial on the right side of the watch, near the number "3." Turn the dial counterclockwise until it feels loose. Slide a fingernail beneath the crown dial and pull it out as far as it will go. The watch will stop telling the time. Turn the crown dial clockwise until the hour and minute hands show the correct time. Pay attention to the small 24-hour clock face at the top of the watch near the number "12." Its hands move with the hour and minute hands as you turn the crown. Make sure that the hour, minute and 24-hour dial are all showing the correct time. Push the crown dial back down as far as possible. Turn the crown dial clockwise to wind your watch mechanism. The watch's hands will start moving again. Tap the "Mode/Next" button in the bottom left corner of the watch until the time appears. Hold the "Set/Done" button in the top left corner of the watch. Push "+" on the top right or "-" on the bottom right corner of the watch to switch between the time format you want to adjust. Push "Mode/Next" in the bottom left. The hour digits will flash. Push "Mode/Next" until "12 Hour" appears. Push "+" the display will change to "24 Hour." Press "Set/Done" in the top left corner. The watch will exit the setup mode and the time will appear in 24-hour format. To change from military time on your Timex Marathon, simply press and hold the Set button until the watch enters settings mode. Then use the Mode button to navigate to the time format setting and use the + and - buttons to switch between military and standard time. How do I set the alarm on my Timex Marathon watch? To set the alarm on your Timex Marathon watch, press and hold the Alarm button until the hour starts to flash. Then use the + and - buttons to set the desired alarm. Is this article helpful to you? How do I change the time on my Timex Marathon watch? To change the time on your Timex Marathon watch, press and hold the Set button until the watch enters settings mode. Then use the Mode button to navigate to the time zone setting and use the + and - buttons to select the desired time zone. How do I calibrate the compass on my Timex Marathon watch? To calibrate the compass on your Timex Marathon watch, press and hold the Set button until the watch enters settings mode. Then use the Mode button to navigate to the compass calibration setting and follow the on-screen instructions. Can I swim with my Timex Marathon watch? Yes, the Timex Marathon watch is water-resistant and can be worn while swimming. How do I replace the battery in my Timex Marathon watch? To replace the battery in your Timex Marathon watch, remove the back cover using a small screwdriver, then carefully replace the old battery with a new one, ensuring it is placed in the correct position. How do I clean the band of my Timex Marathon watch? To clean the band of your Timex Marathon watch, simply use a mild detergent and water, then rinse and dry thoroughly before wearing again. Can I change the strap on my Timex Marathon watch? Yes, the strap on your Timex Marathon watch can be easily replaced with a compatible strap of your choice. How do I enable the backlight on my Timex Marathon watch? To enable the backlight on your Timex Marathon watch, simply press the Indiglo button to illuminate the display. How do I lock the buttons on my Timex Marathon watch? To lock the buttons on your Timex Marathon watch, press and hold the Set and Mode buttons simultaneously for a few seconds. Repeat the process to unlock the buttons. How long is the warranty on my Timex Marathon watch? The warranty on your Timex Marathon watch is typically one year from the date of purchase. See 3,000+ New Gun Deals HERE Can I track my workouts with my Timex Marathon watch? Yes, the Timex Marathon watch has features for tracking workouts, such as a stopwatch and interval timer. See 3,000+ New Gun Deals HERE How do I reset my Timex Marathon watch? To reset your Timex Marathon watch, press and hold all buttons simultaneously for a few seconds, then release and reset the time and settings as needed. John Howard/Digital Vision/Getty Images You can set your digital Timex watch to display military, or 24-hour, time. In other words, 1:00pm would display as 13:00 and 12:30am would display as 00:30. Instructions may vary somewhat between models, but the general approach is the same. Press the "MODE" button usually on the lower left side of the watch, but sometimes on the right center sideto cycle through to the time display. Press and hold the "SET" button usually on the right lower side of the watch until the seconds flash. Press "MODE" repeatedly to cycle through the displays that flash: from hours to minutes to month to date and day. At the end of the cycle is the hour display option. Select this option flash. Press the "SPLIT/RESET" button below the face of the watch to change the hour display option to "24-hour display." This is the same as military time. If there is a "NEXT" button on the upper-right side of the watch, use this to advance to the 24-hour option instead of using the "SPLIT/RESET" button. You may need to press a "START/SPLIT" button instead a "SPLIT/RESET" button to cycle between 12- and 24-hour display. The "START/SPLIT" button could be located below the watch face or on the upper-right side of the watch, depending on the model. Press the "SET" button again. You are now done. All PM hours should be displaying hours between 12 and 23.

## How to change timex watch from military time. Timex marathon change from military time. How do i change the time on my timex marathon watch.